

[www.injectionpumps.co.uk](http://www.injectionpumps.co.uk)

# Bryce

**Spare Parts Lists for  
A and B size Pumps**

---

**Types FAOAB  
FAOAN  
FAOAR**

ITEM	Part Name	FAOAB065A6368 BPF1A65AS6368	FAOAB060A6453 BPF1A60AS6453	FAOAB060A6550 BPF1A60AS6550	FAOAB065A6587 BPF1A65AY6587M	FAOAB060A6656 BPF1A60AS6656		
1	Pump housing	7032/2H	7032/2T	7032/100	7032/205A	7032/2T		
2	Bush - control rod	—	—	—	1/151	—		
3	Element assembly	1/311	1/290	1/290	1/311	1/290		
4	Screw - barrel locating	7032/134	7032/134	7032/134	7032/134	7032/134		
5	Washer - locating screw	7033/379	7033/379	7033/379	7033/379	7033/379		
6	Control rod	7032/10	7032/10	7032/10	7032/208	7032/10		
7	Screw - vent	—	1/126	—	—	1/126		
8	Washer - vent screw	—	NW5/12	—	—	NW5/12		
9	Control sleeve	7032/9	7032/9	7032/9	7032/9	7032/9		
10	Spring plate - upper	7032/11	7032/11	7032/11	7032/11	7032/11		
11	Spring - plunger	1/123	1/123	1/123	1/123	1/123		
12	Spring plate - lower	7032/209	7032/209	7032/209	7032/209	7032/209		
13	Tappet	7032/17	7032/17	7032/17	7032/17	7032/17		
14	Circlip - lower	1/4429	1/4429	1/4429	1/4429	1/4429		
16	Delivery valve and seat assy	1/334	1/342	7032/7	7032/7	7032/7		
17	Spring - delivery valve	7032/7	7032/7	7032/7	7032/7	7032/7		
19	Seal - high pressure	5936/22	5936/22	5936/22	5936/22	5936/22		
20	Delivery valve holder	7032/3	7032/3	7032/3	7032/3	7032/3		
21	Spring peg	—	13/158	—	—	13/158		
22	Adaptor - inlet connector	7032/133	—	7027/12	7027/12	—		
24	Washer - inlet adaptor	NW5/49	—	NW5/49	NW5/49	—		

Bryce

FAOAB...A

ITEM	Part Name	FAOAB060B0015 A1AA60/5S15AV	FAOAB080B0015 A1AA80/5S15AV	FAOAB070B0092 A1AA70/5S92H	FAOAB070B0111 A1AA70/5S111H	FAOAB050B0139 A1AA60/5S139H	FAOAB075D0217 A1AA75/7S217	
1	Pump housing	1/458A	1/458A	1/458D	1/458C	1/458C	1/458E	
2	Bush - control rod	1/170	1/170	1/170	1/170	1/170	1/151	
3	Element assembly	1/86C	1/86G	1/86D	1/86D	1/86B	1/86H	
4	Screw - barrel locating	123/9	123/9	123/9	123/9	123/9	123/9	
5	Washer - locating screw	106/118	106/118	106/118	106/118	106/118	106/118	
6	Control rod	1/60	1/60	1/60	1/60	1/60	1/272	
7	Screw - vent	—	—	—	1/126	1/126	1/126	
8	Washer - vent screw	—	—	—	106/62	106/62	106/62	
9	Control sleeve	1/74	1/74	1/74	1/74	1/74	1/74	
10	Spring plate - upper	13/209	13/209	13/209	13/209	13/209	13/209	
11	Spring - plunger	1/123	1/123	1/123	1/123	1/123	1/123	
12	Spring plate - lower	1/148	1/148	1/148	1/148	1/148	1/148	
13	Tappet	1/4430	1/4430	1/4430	1/4430	1/4430	1/4430	
14	Circlip - lower	1/4429	1/4429	1/4429	1/4429	1/4429	1/4429	
15	Delivery valve group items 16-19	1/80A	1/80A	1/80A	1/80C	1/80C	—	
16	Delivery valve and seat assy	—	—	—	—	—	1/367X	
17	Spring - delivery valve	—	—	—	—	—	7032/7	
18	Spring - delivery valve stop	—	—	—	—	—	—	
19	Seal - high pressure	1/81	1/81	1/81	1/81	1/81	1/369	
20	Delivery valve holder	1/78	1/78	1/78	1/78	1/78	1/370	
22	Adaptor - inlet connector	—	—	—	—	—	1/91	
31	Bellows	—	—	—	—	—	1/152	

\* Not supplied separately

Bryce

FAOAB... B,D

ITEM	Part Name	FAOAB070C0177 A1AA70/6S177H	FAOAB070C0178 A1AA70/6S178H	FAOAB050C0179 A1AA50/6S179A	FAOAB050C0180 A1AA50/6S180A	FAOAB080C0210 A1AA80/6S210A	FAOAB080C0215 A1AA80/6S215A	FAOAB080C0280 A1AA80/6S280
1	Pump housing	1/458B	1/458B	1/458B	1/458B	1/458B	1/458B	1/458B
2	Bush - control rod	1/151	1/151	1/151	1/151	1/151	1/151	1/151
3	Element assembly	1/86D	1/86D	1/86B	1/86B	1/559	1/559	1/559
4	Screw - barrel locating	123/9	123/9	123/9	123/9	123/9	123/9	123/9
5	Washer - locating screw	106/118	106/118	106/118	106/118	106/118	106/118	106/118
6	Control rod	1/153	1/157	1/153	1/157	1/153	1/157	1/153
7	Screw - vent	1/126	1/126	1/126	1/126	1/126	1/126	1/126
8	Washer - vent screw	106/62	106/62	106/62	106/62	106/62	106/62	106/62
9	Control sleeve	1/74	1/74	1/74	1/74	1/74	1/74	1/74
10	Spring plate - upper	13/209	13/209	13/209	13/209	13/209	13/209	13/209
11	Spring - plunger	1/123	1/123	1/123	1/123	1/123	1/123	1/123
12	Spring plate - lower	1/148	1/148	1/148	1/148	1/148	1/148	1/148
13	Tappet	1/4430	1/4430	1/4430	1/4430	1/4430	1/4430	1/4430
14	Circlip - lower	1/4429	1/4429	1/4429	1/4429	1/4429	1/4429	1/4429
16	Delivery valve and seat assy	13/154C	13/154C	13/154B	13/154B	13/154C	13/154C	1/594
17	Spring - delivery valve	13/157	13/157	13/157	13/157	13/157	13/157	13/157
19	Seal - high pressure	13/82	13/82	13/82	13/82	13/82	13/82	13/82
20	Delivery valve holder	13/152	13/152	13/152	13/152	13/152	13/152	1/287
21	Spring peg	13/158	13/158	13/158	13/158	13/158	13/158	13/158
31	Bellows*	1/152	1/152	1/152	1/152	1/152	1/152	1/152

\* Not supplied with spare pumps. To be ordered separately.

**Bryce**

**FAOAB...C**

ITEM	Part Name	FAOAB065C0290 A1AA65/6S290	FAOAB070C0292 A1AA70/6S292	FAOAB080C0295 A1AA80/6S295	FAOAB090C0457 -	FAOAB080C0531 -	FAOAB080C0626 -	FAOAB080C0700 -
1	Pump housing	1/458B	1/458B	1/458B	1/456	1/458F	1/458F	1/458B
2	Bush - control rod	1/151	1/151	1/151	-	1/151	1/151	1/151
3	Element assembly	1/86E	1/86D	1/559	1/455	1/541	1/86G	1/559
4	Screw - barrel locating	123/9	123/9	123/9	123/9	123/9	123/9	123/9
5	Washer - locating screw	106/118	106/118	106/118	106/118	106/118	106/118	106/118
6	Control rod	1/153	1/153	1/157	1/451	1/153	1/153	1/153
7	Screw - vent	1/126	1/126	1/126	1/126	1/126	1/126	1/126
8	Washer - vent screw	106/62	106/62	106/62	106/62	106/62	106/62	106/62
9	Control sleeve	1/74	1/74	1/74	1/74	1/74	1/74	1/74
10	Spring plate - upper	13/209	13/209	13/209	13/209	13/209	13/209	13/209
11	Spring - plunger	1/123	1/123	1/123	1/123	1/123	7033/334	7033/354
12	Spring plate - lower	1/148	1/148	1/148	1/148	1/148	1/148	1/148
13	Tappet	1/4430	1/4430	1/4430	1/4430	1/4430	1/4430	1/4430
14	Circlip - lower	1/4429	1/4429	1/4429	1/4429	1/4429	1/4429	1/4429
16	Delivery valve and seat assy	13/154C	13/154C	1/594	13/154B	1/539	13/154C	13/154C
17	Spring - delivery valve	13/157	13/157	13/157	13/157	13/157	13/157	13/157
19	Seal - high pressure	13/82	13/82	13/82	13/82	13/82	13/82	13/82
20	Delivery valve holder	13/152	13/152	1/287	1/453	13/152	13/152	13/152
21	Spring peg	13/158	13/158	13/158	-	13/158	13/158	13/158
28	Buffer	-	-	-	1/452	-	-	-
29	Grub screw	-	-	-	250/15F	-	-	-
30	Lead slot	-	-	-	170/1	-	-	-
31	Bellows*	1/152	1/152	1/152	-	1/152	1/152	1/152

\* Not supplied with spare pumps. To be ordered separately.

**Bryce**

**FAOAB...C**

ITEM	Part Name	FAOAB070P0431	FAOAB075P0449 BPF1A75P00	FAOAB080P0454	FAOAB065P0458	FAOAB085P0458	FAOAB075P6310 BPF1A75P6310	FAOAB070P6365 BPF1A70P6365
1	Pump housing	* Order Pump	7032/2P	7032/2S	1/448	1/448	7032/2M	7032/100D
3	Element assembly	1/313	1/315	1/312	1/310	1/561	1/315	1/313
4	Screw - barrel locating	7032/134A	7032/134A	7032/134A	7032/134A	7032/134A	7032/134A	7032/134A
5	Washer - locating screw	7033/379	7033/379	7033/379	7033/379	7033/379	7033/379	7033/379
6	Control rod	7032/10	7032/10	7032/10	7032/10	7032/10	7032/10	7032/10
7	Screw - vent	1/126	—	1/126	—	—	—	—
8	Washer - vent screw	NW5/12	—	NW5/12	—	—	—	—
9	Control sleeve	7032/9	7032/9	7032/9	7032/9	7032/9	7032/9	7032/9
10	Spring plate - upper	7032/11	7032/11	7032/11	7032/11	7032/11	7032/11	7032/11
11	Spring - plunger	1/123	1/123	7033/334	1/123	1/123	1/123	1/123
12	Spring plate - lower	7032/209	7032/209	7032/209	7032/209	7032/209	7032/209	7032/209
13	Tappet	7032/17	7032/17	7032/17	7032/17	7032/17	7032/17	7032/17
14	Circlip - lower	1/4429	1/4429	1/4429	1/4429	1/4429	1/4429	1/4429
16	Delivery valve and seat assy	1/338	1/334	1/342	1/334	1/334	1/343	1/334
17	Spring - delivery valve	7032/7	7032/7	7032/7	7032/7	7032/7	7032/7	7032/7
19	Seal - high pressure	5936/22	5936/22	5936/22	5936/22	5936/22	5936/22	5936/22
20	Delivery valve holder	7033/97	7032/3	7033/97	7032/3	7032/3	7033/97	7033/3
21	Spring peg	13/158	—	13/158	—	—	13/158	—
22	Adaptor - inlet connector	—	7027/12	—	—	—	7027/12	7027/12
24	Washer - inlet adaptor	—	NW5/49	—	—	—	NW5/49	NW5/49
*	Replacement pump	FAOAB070P6657	—	—	—	—	—	—

Bryce

FAOAB...P

ITEM	Part Name	FAOAB075P6448 BPF1A75P6448	FAOAB060P6656	FAOAB070P6657 BPF1A70P6657	FAOAB075P6657	FAOAB075P6659 BPF1A75P6659		
1	Pump housing	7032/2S	7032/2S	7032/2S	7032/2S	7032/2S		
3	Element assembly	1/314	1/448C	1/313	1/315	1/314		
4	Screw - barrel locating	7032/134A	7032/134A	7032/134A	7032/134A	7032/134A		
5	Washer - locating screw	7033/379	7033/379	7033/379	7033/379	7033/379		
6	Control rod	7032/10	7032/10	7032/10	7032/10	7032/10		
7	Screw - vent	1/126	1/126	1/126	1/126	1/126		
8	Washer - vent screw	NW5/12	NW5/12	NW5/12	NW5/12	NW5/12		
9	Control sleeve	7032/9	7032/9	7032/9	7032/9	7032/9		
10	Spring plate - upper	7032/11	7032/11	7032/11	7032/11	7032/11		
11	Spring - plunger	1/123	7033/334	7033/334	7033/334	7033/334		
12	Spring plate - lower	7032/209	7032/209	7032/209	7032/209	7032/209		
13	Tappet	7032/17	7032/17	7032/17	7032/17	7032/17		
14	Circlip - lower	1/4429	1/4429	1/4429	1/4429	1/4429		
16	Delivery valve and seat assy	1/338	1/338	1/338	1/338	1/338		
17	Spring - delivery valve	7032/7	7032/7	7032/7	7032/7	7032/7		
19	Seal - high pressure	5936/22	5936/22	5936/22	5936/22	5936/22		
20	Delivery valve holder	7033/97	7033/97	7033/97	7033/97	7033/97		
21	Spring peg	13/158	13/158	13/158	13/158	13/158		

Bryce

FAOAB...P

ITEM	Part Name	FAOAN075B0373 A1DA75/7S373	FAOAN090B0429 -	FAOAN075B0447 FAOAN075X0447	FAOAN075B0513 -	FAOAN075B0520 -	FAOAN075B0543 -	FAOAN100B0575 FAOAN100X0575
1	Pump housing	1/375B	1/473	1/538	1/375B	1/375B	1/538	1/590
2	Element assembly	1/337H	1/474	1/377H	1/402H	1/491A	1/491A	1/585
3	Screw - barrel locating	123/9	123/9	123/9	123/9	123/9	123/9	123/15
4	Washer - barrel locating screw	106/118	106/118	106/118	106/118	106/118	106/118	106/118
6	Control sleeve	1/399	1/399	1/399	1/399	1/399	1/399	1/588
7	Spring plate - upper	1/383	1/383	1/383	1/383	1/383	1/383	1/383
8	Spring - plunger	1/489	1/477	1/489	1/465	1/489	1/489	1/477
9	Spring plate - lower	1/445	1/478	1/445	1/445	1/445	1/445	1/478
11	Delivery valve and seat Assy	1/367Z	1/367X	1/367Z	1/367Z	1/490A	1/490A	1/367X
12	Spring peg	1/430	13/158	1/430	1/430	1/430	1/430	13/158
13	Spring - delivery valve	7032/7	7032/7	7032/7	7032/7	7032/7	7032/7	7032/7
14	Seal - high pressure	1/369	1/546	1/369	1/369	1/369	1/369	1/546
15	Delivery valve holder	1/429	1/370	1/429	1/429	1/429	1/429	1/370
16	Screw - vent	1/126	-	1/126	1/126	1/126	1/126	-
17	Washer - vent screw	106/62	-	106/62	106/62	106/62	106/62	-

Bryce

FAOAN...B

ITEM	Part Name	FAOAN065P0578	FAOAN065P0680					
1	Pump housing	1/562	1/562					
2	Element assembly	1/421	1/421					
3	Screw - barrel locating	7032/134A	7032/134A					
4	Washer - barrel locating screw	7033/379	7033/379					
5	Circlip - upper	1/566	1/566					
6	Control sleeve	1/563	1/591					
7	Spring plate - upper	7032/11	7032/11					
8	Spring - plunger	7033/334	7033/334					
9	Spring plate - lower	1/567	1/567					
10	Circlip - lower	124/58	124/58					
11	Delivery valve and seat Assy	1/338	1/342					
12	Spring peg	13/158	13/158					
13	Spring - delivery valve	7032/7	7032/7					
14	Seal - high pressure	5936/22	5936/22					
15	Delivery valve holder	7033/97	7033/97					
16	Screw - vent	1/126	1/126					
17	Washer - vent screw	NW5/12	NW5/12					

Bryce

FAOAN...P

Part Name	FAOAR055E0613	FAOAR055E0614	FAOAR055E0615	FAOAR070E0625 FAOAR070X0625	FAOAR070E0631		
Pump housing	11/101	11/101	11/101	11/101	11/101		
Element assembly	11/108 BA	11/108 BB	11/108 BC	11/109 EA	11/109 EB		
Plug - barrel locating	11/114	11/114	11/114	11/114	11/114		
Circlip - housing	11/131	11/131	11/131	11/131	11/131		
Control rod assembly	11/116	11/116	11/116	11/116	11/116		
Control sleeve	11/128	11/128	11/128	11/128	11/128		
Spring plate - upper	11/119	11/119	11/119	11/119	11/119		
Spring - plunger	11/120	11/120	11/120	11/120	11/120		
Spring plate - lower	11/129	11/129	11/129	11/129	11/129		
Tappet body	11/130	11/130	11/130	11/130	11/130		
Delivery valve and seat assy	11/103A	11/103 AB	11/103 AB	11/103 A	11/103 B		
Spring peg	11/107	11/107	11/107	11/107	11/107		
Spring - delivery valve	1/326	11/152	1/326	1/326	1/326		
Seal - high pressure	11/121	11/121	11/121	11/121	11/121		
Seal "O" ring	235/33	235/33	235/33	235/33	235/33		
Delivery valve holder	11/106F	11/106F	11/106F	11/106A	11/106A		
Roller - tappet	11/123	11/123	11/123	11/123	11/123		
Bush - roller	11/132	11/132	11/132	11/132	11/132		
Pin - bush	11/124	11/124	11/124	11/124	11/124		
Guide pin - tappet	11/125	11/125	11/125	11/125	11/125		
Shim	11/126 A-M	11/126 A-M	11/126 A-M	11/126 A-M	11/126 A-M		
Plug - expansion core	11/140	11/140	11/140	11/140	11/140		
TABLE OF SHIM THICKNESS							
	11/126A - 0.30 mm	11/126G - 0.56 mm					
	11/126B - 0.41 mm	11/126H - 0.59 mm					
	11/126C - 0.44 mm	11/126J - 0.62 mm					
	11/126D - 0.47 mm	11/126K - 0.65 mm					
	11/126E - 0.50 mm	11/126L - 0.68 mm					
	11/126F - 0.53 mm	11/126M - 0.98 mm					

FAOAR...E

[www.injectionpumps.co.uk](http://www.injectionpumps.co.uk)